




Program Selector for Sliding Doors



To Lock The Programme Selector



To Unlock The Programme Selector
repeat the same procedure as above
and the Cross will disappear